



Spring isolation bushing assemblies provide:

1. Equal tension on all wire ropes
2. Isolation of all metal parts between sockets, springs and hitch plate for noiseless operation. Spring isolation bushings assemblies are provided with springs, bushings and washers specifically sized for the speed and capacity of elevators. There are two basic models; EM901 and EM1001. Others sizes are available including EM400 for larger diameter ropes.

Spring isolation bushing assemblies include;

- 1 pce Spring
- 3 pcs Plastic bushings (top hats)
- 2 pcs Bushing washers
- 1 pce Rod washer



Burnaby / Vancouver

7832 Enterprise Street Burnaby BC V5A 1V7 Phone: 604-292-1220

Langley / Surrey

Unit 1, 9663-199A Street Langley BC V1M 2X7 Phone: 604-881-3000

Kelowna / Interior

378 Totom Ave Kelowna BC V1X 7T5 Phone: 250-491-1055

For more information on Lifting & Rigging equipment inspection & safe use consult our literature or visit: www.wescovan.com